

# AUDICA

Installation Manual for:

## **multi**zone

4 zone controller




## Contents

Overall Description	3
Technical specification	3
Front Panel Controls	4
Rear Panel Connectors and Controls	4
Appendix 1 Microphone compressor and ducker operation	8
Appendix 2 Remote Zone Controller connections	8
Appendix 3 LOOP input and output connections	8
Appendix 4 RS-232 Interface	8



Dans la documentation qui accompagne cet appareil, ce symbole indique des instructions d'utilisation et d'entretien essentielles.



Ce symbole indique la présence dans cet appareil d'un voltage dangereux, qui peut poser un risque de choc électrique..

**Read these instructions.**  
**Keep these instructions.**  
**Heed all warnings.**  
**Follow all instructions.**

### 1. PRECAUTIONS

**WARNING** - To reduce the risk of electric shock do not remove any panels or covers. There are no user serviceable parts in this product.

**WARNING** - To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

**READ ALL INSTRUCTIONS** before attempting to install or use the product.

**RETAIN INSTRUCTIONS** for future reference.

**WATER AND MOISTURE** – Do not use this product near water, for example sinks, bath tubs, wet areas and the like. The product shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the product.

**OBJECT OR LIQUID ENTRY** - Do not insert any object or liquid into the openings in the product as this may cause electric shock or malfunction.

**HEAT** – Do not install the product near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.

**CLEANING** – Clean only with a dry cloth.

**MOVING/TRANSPORTING THE PRODUCT** – The product should be packed in its original packaging for moving from location to location.

**OVERLOADING** - Never overload mains outlets, extension cables or multi-way plug extensions as this may cause fire or electric shock.

**POWER CORD** – Do not defeat the safety purpose of the grounding-type plug. The plug has two blades and a third grounding prong. The third prong is provided for your safety. If the provided plug does not fit your outlet, consult and electrician for replacement of the obsolete outlet.

**POWER CORD PROTECTION** – Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where it exits from the apparatus.

**ACCESSORIES** – Use only attachments/accessories specified by the manufacturer.

**CARTS/STANDS** – Use only with the cart, stand, tripod, bracket or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

**LIGHTNING** – Unplug this apparatus during lightning storms or when unused for long periods of time.

### 2. SERVICING

Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled, or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not attempt to service this product yourself as opening covers or panels may expose you to dangerous voltages or other hazards.

Where replacement parts are required be sure the service technician has used replacements supplied by the manufacturer or have the same characteristics as the original part. Use of unsuitable parts could cause fire, electric shock or other hazards and may void any warranty or guarantee.


The technician must perform any safety checks to test the performance of the product upon completion of any repairs.

## Overall Description:

The Audica Professional MULTIZone is a zone control mixer with 4 zone outputs and 6 music inputs plus a microphone input for paging applications. Each of the 4 zone outputs can be independently configured to provide music from one of the inputs plus the paging microphone, with the relative levels set by front panel controls. When the microphone is used, the music is automatically reduced in level (“ducking”) to allow for announcements to be heard clearly. Each zone output is mono but all inputs are stereo capable (mixed to mono internally).

Zone outputs can have Audica speaker EQ applied if needed. A mute control input is provided to be linked to fire control systems. This mutes all music inputs whilst keeping the paging microphone active for safety announcements.

Remote zone control is possible via wired wall-mount control panels or an RS-232 interface.



## Technical specification


### Inputs

Line inputs	Input impedance	10k $\Omega$ at maximum gain – increases as gain is reduced
	Input voltage range for full scale	240mV (maximum gain) – 6.4V (minimum gain)
Microphone input	Input impedance	10k $\Omega$ balanced
	Input voltage range for full scale	4mV (maximum gain) – 3.3V (minimum gain)

### Outputs

Zone outputs - Line	Output impedance	200 $\Omega$
	Maximum output level	1.8 Vrms
Zone outputs - Balanced	Output impedance	400 $\Omega$
	Maximum output level	3.6 Vrms

## Front Panel Controls



### a) Input Select

Choose one line input channel (1 to 6) to send to each zone output (1 to 4).

### b) Zone Volume

Set the volume level for each zone (1 to 4). Turn clockwise to increase volume, anticlockwise to decrease.

### c) Mic Volume

Four screwdriver controls set the volume level from the paging microphone mixed with each zone's music signal (zones 1 to 4). When set to zero, music ducking (see Appendix 1) is disabled for that zone.

### d) Zone signal indicator

This white indicator LED illuminates when a signal is present. The brightness of the LED gives some indication of the signal level.


### e) Power On/Off

This is a true mechanical power switch (not a standby mode). Its position is retained even during mains power failure.

### f) Power on indicator

This blue indicator LED is off when the power switch is off and lights blue when the mains power is on. Rapid flashing indicates that the RS-232 enabled standby mode is in operation.

## Rear Panel Connectors and Controls



### a) Mains power input

IEC 3-pin connector. Use power cord supplied.  
WARNING – The power cord must be connected to a power socket outlet with a protective earth connection.

### b) Line Inputs

Six line input channels on RCA phono pairs, each of which can accept a mono or stereo source (stereo sources are internally mixed down to mono). The front panel Input Select switches (see above) pick which channel is to be sent to each Zone output.

### c) Line input gain controls

Rotary potentiometer to set gain for input channels 1, 2, 3, 4, 5 and 6.

### d) Input level set aid

A single 2-colour LED is provided to assist setting the line input levels. By applying a signal on each input in turn the level can be set optimally. Green indicates the signal is in the optimum range (>-20dB) and Red indicates that clipping is imminent (>-2dB)


### e) Zone Outputs (unbalanced)

Four mono RCA phono sockets carry the Zone (Line) outputs. Each Zone Output can be selected to have a flat frequency response or the Audica speaker EQ (AEQ) equalisation (see page 6).

### f) Zone Outputs (balanced)

Balanced audio outputs are provided on 3-way Phoenix connectors for Zones 1, 2, 3 and 4. These replicate RCA jack outputs for each zone. The balanced output level is double the unbalanced output.

If taking a single-ended output from the balanced output terminals then use the ground pin for screen and '+-' pin for signal. DO NOT connect the '-' output pin to ground.



**g) Microphone Input**

An XLR balanced input for a paging microphone. A 48V “phantom power” option is provided for active or condenser microphones – selected via the DIL switch (see next page). The microphone signal can be processed in various ways using 6 rotary potentiometers.

**g1) GAIN**

Rotary potentiometer sets the gain of the microphone input – to accommodate different microphones. Since the gain range on the Mic input is +50dB to -10dB this can also be used as a line level input (maximum input 3.3Vrms).

**g2) COMPRESSION RATIO**

Rotary potentiometer sets the compressor contribution to microphone channel.

**g3) TREBLE**

Mid-high tone control on microphone channel (centred at 5kHz).

**g4) BASS**

Low-mid tone control on microphone channel (centred at 150Hz).

**g5) DUCKER – FLOOR**

Rotary potentiometer sets the music ducking “floor level” (music attenuation level).


**g6) DUCKER – RELEASE**

Rotary potentiometer sets the music ducking release time (music fade-up time).

**g7) MIC LEVEL SET AID**

This is a 2-colour LED to assist in MIC input level setting. Green indicates the signal is in the optimum range (>-20dB) and Red indicates that clipping is imminent (>-2dB)

[A more detailed description of the compressor and ducker operation can be found in Appendix 1.



### h) DIP switch

DIP switches are “ON” when down and “OFF” when up. The default setting is with all switches set OFF (up). The table below describes their effect.

SW	Function	DIP switch UP	DIP switch DOWN	Notes
		OFF	ON	
1	RS-232 Address LSB	0	1	Use these switches to set the “unit number” for RS-232 addressing. See Appendix 4 for details. Set all three switches to “0” (UP) to lock the unit into Manual mode – disabling all RS-232 control.
2	RS-232 Address	0	2	
3	RS-232 Address MSB	0	4	
4	RS-232 source – when unit is SLAVE	Unit is controlled from local RS-232 socket	RS-232 control from LOOP input	When unit is master, RS-232 signal is sent to LOOP out – so DIP switch has no effect.
5	MIC source – when unit is SLAVE	Local microphone “ducks” unit’s Zone outputs	Master (LOOP) microphone “ducks” unit’s Zone outputs	When unit is master, ducking signal is sent to LOOP out – so DIP switch has no effect. **
6	Phantom Power	off	on	Phantom power to microphone
7	Zone 1 Audica EQ	off	AEQ	Audica speaker EQ is designed to optimise performance from Audica Pro loudspeakers.
8	Zone 2 Audica EQ	off	AEQ	
9	Zone 3 Audica EQ	off	AEQ	
10	Zone 4 Audica EQ	off	AEQ	


\*\*In a system with only a single MULTIZone unit, if DIP switch 5 is set ON then any microphone signal will “duck” the music signal in whichever zone(s) the microphone level is set above zero – but the microphone signal will not be heard.

### i) Remote Zone Controller inputs

Four RJ-45 sockets for connection to remote Zone Control wall plates. Connect via an 8-way CAT-5 cable terminated with RJ-45 plugs at each end for each Zone. The Zone Control wall plate takes over control of Zone input select and volume control – disabling the front panel controls for that zone. See Appendix 2 for further details.

### j) RS-232 control input

9-pin male “D-type” connector. See Appendix 4 for further details and the RS-232 control protocol.



**k) LOOP input and output connectors**

These are 15-pin D-type connectors (male for Loop out, female for Loop in) for looping the audio inputs (and optionally Mic, Mute and RS-232) to other units. Up to a total of 7 MULTIZONE units can be linked in this way. When a unit has a loop cable connected to its LOOP IN socket it becomes a "Slave". The unit which has nothing plugged into its LOOP IN socket is the Master unit. See Appendix 3 for further details.

**l) MUTE input**


Some buildings require that the music system is muted if the fire alarm is triggered. Two types of input are provided on the unit for this purpose - on a 4-way Phoenix connector.

The first two pins accept a DC voltage input (5-30V) for muting.

The third and fourth pins may be wired to Normally Open isolated contacts (e.g. a relay activated by the fire control panel).

The sense of the Mute input can be reversed by an internal jumper such that a Normally Closed contact or absence of the 5-30V causes muting instead. The internal jumper, plugged into CON302, is located at the front edge of the main PC board, adjacent to the left hand ribbon cable from the front panel – see below

Location of jumper V=not muted or NC contacts



Location of jumper V=mute or NO contacts (default)

## Appendix 1

### Microphone compressor and ducker operation

A variable compressor effect is provided to help level out differences in loudness caused by different microphone users. This also helps prevent overload of the loudspeakers from any knock or pop noises received by the microphone or the differing mic technique of various users. The "Compression Ratio" control adjusts the balance between compressed and uncompressed mic signal. Fully counterclockwise delivers uncompressed audio, fully clockwise delivers only the compressor output.

The mix of the microphone signal into each zone is controlled by its "preset" rotary control, adjustable via a screwdriver on the front panel. When the microphone signal exceeds a threshold the zone's music level is reduced automatically to a level which allows the microphone signal to be clearly heard. The rear panel "Ducker Floor" control adjusts the degree of music attenuation applied. The "Ducker Release" control adjusts the time delay before the music fades back up again.

Note: The ducker will action will only take effect in zones whose front panel "mic vol" control is set above zero.

## Appendix 2

### Remote Zone Controller connections

Pin No.	Connection
1	Ground
2	+3.3V
3	Control
4	Volume (DC voltage)
5	Source select (DC voltage)
6	+3.3V
7	Ground
8	+5V

The "Control" line may be used to disable the remote wall control plate and revert to front panel control. If the "Control" line is shorted to ground via a switch, the zone reverts to front panel control. A red LED back-illuminates the wall plate to indicate that that the controls are disabled.

## Appendix 3

### LOOP input and output connections

Pin No.	Connection
1	Ground
2	-6V LOOP
3	+6V LOOP
4	SLAVE_DETECT (grounded by Master Loop-out)
5	MUTE_LOOP
6	RS-232_LOOP
7	DUCKER_LOOP
8	Ground
9	Master unit input source 1
10	Master unit input source 2
11	Master unit input source 3
12	Master unit input source 4
13	Master unit input source 5
14	Master unit input source 6
15	Mic Signal loop

## Appendix 4

### RS-232 Interface

An RS-232 control interface allows remote control of all basic functions of MULTIZone. The RS-232 interface is uni-directional, MULTIZone does not transmit any data. Commands will be sent as RS-232 serial communication at 9600 baud, 8 bits, no parity bits, 1 stop bit and no flow control. All characters will be sent as ASCII, not delimited and ending with a carriage return.

Multiple MULTIZone units can either be addressed and controlled from separate RS-232 control sources, or alternatively the user is able to set an address for each MULTIZone unit via its rear panel switches, allowing multiple chained units to be controlled from a single RS-232 control source. If this feature is required, then the user simply sets the RS-232 source to "LOOP" via the rear panel switch (DIP switch #4) and assigns a different address for each MULTIZone unit (DIP switches 1, 2 and 3). RS-232 data is then relayed to each looped unit using the same cable as the signal loop-through.



A DIP switch setting “000” locks the unit into manual panel mode, disabling all RS-232 control for that unit – see page 6.

**Note: when using RS-232 control, no more than 7 units can be looped using a single RS-232 controller (i.e. up to 28 zones).**

A structure of RS-232 commands is provided that allow operation of MULTIZone at the ‘system’ level, ‘unit’ level or ‘zone’ level. System commands cause every MULTIZone to respond. Unit commands cause only the addressed unit to respond. Zone commands cause only the selected zone on a selected unit to respond.

The RS-232 interface has additional functionality in that it can be used to put MULTIZone in standby. A specific “sbyoff” command will reduce power consumption to <0.5W by shutting down all internal systems. An “sbyon” command will then restore system operation but it is important to note that the unit will take several seconds to fully awake, during which time no audio will be heard and no other RS-232 commands can be received or acted upon. The programming of the RS-232 source device must take this into consideration.

**RS-232 connector wiring**

Pin No.	Connection
1	No connection
2	RS-232 receive (RX)
3	No connection
4	No connection
5	Ground
6	No connection
7	No connection
8	No connection
9	No connection

**System command format**

Command Type	RS-232 Command	MULTIZone command response
SYSTEM	\$s99sbyoff	All units enter standby mode
SYSTEM	\$s99sbyon	All units power up out of standby
SYSTEM	\$s99muten	All units all zones enter mute
SYSTEM	\$s99mutdis	All units all zones de-mute
SYSTEM	\$s99comen	All units all zones enter RS-232 control mode
SYSTEM	\$s99comdis	All units all zones enter manual front panel control mode

**Unit command format**

Command Type	RS-232 Command	MULTIZone command response
UNIT	\$sXXsbyoff	Unit Y enters standby
UNIT	\$sXXsbyon	Unit Y powers up from standby
UNIT	\$sXXmuten	Unit Y all zones enter mute
UNIT	\$sXXmutdis	Unit Y all zones de-mute
UNIT	\$sXXcomen	Unit Y all zones enter RS-232 control mode
UNIT	\$sXXcomdis	Unit Y all zones enter manual front panel control mode

Where XX =	Responding unit Y DIP switch address
01	1
05	2
09	3
13	4
17	5
21	6
25	7

## Zone command format

As a number of MULTIZone units can be looped together the zone command should refer to the absolute zone within the loop. i.e. in a system with three MULTIZone units, zone 2 of unit 3 would be referenced as zone 10.

Command Type	RS-232 Command	Note	DIP switch setting		
			Switch 3	Switch 2	Switch 1
UNIT	\$s01<CMD>	Command only applies to unit1 zone 1	0	0	1
UNIT	\$s02<CMD>	Command only applies to unit1 zone 2	0	0	1
UNIT	\$s03<CMD>	Command only applies to unit1 zone 3	0	0	1
UNIT	\$s04<CMD>	Command only applies to unit1 zone 4	0	0	1
UNIT	\$s05<CMD>	Command only applies to unit 2 zone 1	0	1	0
UNIT	\$s06<CMD>	Command only applies to unit 2 zone 2	0	1	0
UNIT	\$s07<CMD>	Command only applies to unit 2 zone 3	0	1	0
UNIT	\$s08<CMD>	Command only applies to unit 2 zone 4	0	1	0
UNIT	\$s09<CMD>	Command only applies to unit 3 zone 1	0	1	1
UNIT	\$s10<CMD>	Command only applies to unit 3 zone 2	0	1	1
UNIT	\$s11<CMD>	Command only applies to unit 3 zone 3	0	1	1
UNIT	\$s12<CMD>	Command only applies to unit 3 zone 4	0	1	1
UNIT	\$s13<CMD>	Command only applies to unit 4 zone 1	1	0	0
UNIT	\$s14<CMD>	Command only applies to unit 4 zone 2	1	0	0
UNIT	\$s15<CMD>	Command only applies to unit 4 zone 3	1	0	0
UNIT	\$s16<CMD>	Command only applies to unit 4 zone 4	1	0	0
UNIT	\$s17<CMD>	Command only applies to unit 5 zone 1	1	0	1
UNIT	\$s18<CMD>	Command only applies to unit 5 zone 2	1	0	1
UNIT	\$s19<CMD>	Command only applies to unit 5 zone 3	1	0	1
UNIT	\$s20<CMD>	Command only applies to unit 5 zone 4	1	0	1
UNIT	\$s21<CMD>	Command only applies to unit 6 zone 1	1	1	0
UNIT	\$s22<CMD>	Command only applies to unit 6 zone 2	1	1	0
UNIT	\$s23<CMD>	Command only applies to unit 6 zone 3	1	1	0
UNIT	\$s24<CMD>	Command only applies to unit 6 zone 4	1	1	0
UNIT	\$s25<CMD>	Command only applies to unit 7 zone 1	1	1	1
UNIT	\$s26<CMD>	Command only applies to unit 7 zone 2	1	1	1
UNIT	\$s27<CMD>	Command only applies to unit 7 zone 3	1	1	1
UNIT	\$s28<CMD>	Command only applies to unit 7 zone 4	1	1	1

Where <CMD> can be	MULTIZone command response	Range of <X>	Notes
vol<X>	Sets absolute volume level of zone	000 to 027	000=MIN, 027=MAX
vol+	Increments volume level of zone	N/A	Will not increment above 027
vol-	Decrements volume level of zone	N/A	Will not decrement below 000
muton	Zone enters mute	N/A	Previous volume level recorded
mutoff	Zone de-mutes	N/A	Previous volume level restored
comon	Zone enters RS-232 control	N/A	Manual panel controls disabled – RS232 settings asserted
comoff	Zone exits RS-232 control	N/A	RS-232 mode disabled – manual panel settings asserted
scr<X>	Selects input source (1 through 6) as zone output	1 to 6	Selects source 1 through 6

Before a zone can be brought under RS-232 control it must first be switched from manual panel mode to RS232 by using the "comon" for a particular zone, or the "comen" system wide or unit command (all described above).

Note: the front panel controls will be disabled when the unit is in RS-232 mode. Make sure the required unit zones are brought out of RS232 by sending the appropriate "comoff" or "comdis" commands.

### Command examples, RS-232 source sends:

\$s99sbyoff<return>	> All units enter standby
\$s04comon<return>	> Turn on RS-232 communications for zone 4
\$s05comoff<return>	> Turn off RS-232 communications for unit 2, zone 1
\$s99comen<return>	> Turn on RS-232 communications for every zone on every unit
\$s09comdis<return>	> Turn off RS-232 communications for every zone on unit 3
\$s02src2<return>	> Sets zone 2 (unit 1 zone 2) to source 2
\$s10src3<return>	> Sets zone 10 (unit 3 zone 2) to source 3
\$s08vo+<return>	> Increments volume on zone 8 (unit 2 zone 4)
\$s03vo-<return>	> Decrements volume on zone 3 (unit 1 zone 3)
\$s14vol012<return>	> Sets absolute volume level of zone 14 (unit 4 zone 2) to level 12
\$s99muten<return>	> Mutes every zone on every unit

When MULTIZone is powered on, the previous status of the unit will be restored. If a particular zone of the unit was previously in RS-232 mode the particular settings for that zone will be restored, e.g. the source input, volume level, or mute. Alternatively, if a particular zone was in manual panel mode the front controls will become active.

# AUDICA

[www.audicapro.co.uk](http://www.audicapro.co.uk)

Our policy is one of continuous product improvement, we reserve the right to change the designs and specifications without notice.

All information is given in good faith. The manufacturer accepts no responsibility for errors, omissions or incorrect assumptions.



This symbol means do not dispose of as municipal waste. Re-use or recycle wherever possible. Electrical/Electronic Equipment may contain substances harmful to the environment. For environmentally sound methods of disposal, please contact your local government agency.