






NUT-RC - Remote control NUT User guide





Volume / Mute

Adjust general volume turning its knob.
The maximum level is reached when all Leds are on.


Press The mute button to activate/desactivate all outputs.
If all LEDs are flashing , all outputs are muted.

Manage Preset


Select a preset turning its knob (9 presets can be managed).
A line is displayed after powering or if the selected preset does not exist.
During preset selection, the preset number is flashing, disappears a few seconds and appears again when the preset is loaded.

Technical Data


Power supply (external)	Input: 100-240VAC 50-60Hz 0.3A Output: 5V $\equiv$ 1.0A
Serial host port	2 RS-232 Ports
Serial communication	Baud Rate: 9600, Stop Bits: 1, Parity: None
Controls	General Volume, Mute all, Presets
Software	NUT software
Mounting	Surface or built-in
Dimensions	82 x 82 x 32 mm
Product/Shipping weight	80g / 200g



Power Supply
AC Adapter 5V



Surface Box



Built-in Box
Legrand 800 41

Accessories (included)

